FIRST AID: Eyes: Immediately hold eyelids apart and flush the eye continuously with running water. Ensure complete irrigation of the eve by keeping eyelids apart and away from eye and moving the eyelids by occasionally lifting the upper and lower lids. Continue flushing until advised to stop by the Poisons Centre or a doctor. or for at least 15 minutes. Transport to hospital or doctor without delay. Removal of contact lenses after an eye injury should only be undertaken by skilled personnel. Skin: Immediately remove all contaminated clothing, including footwear. Flush skin and hair with running water (and soap if available). Seek medical attention in event of irritation. Inhalation: If fumes or combustion products are inhaled remove from contaminated area. Lav patient down. Keep warm and rested. Prostheses such as false teeth, which may block airway, should be removed, prior to initiating first aid procedures. Apply artificial respiration if not breathing, preferably with a demand valve resuscitator, bag-valve mask device, or pocket mask as trained. Perform CPR if necessary, Transport to hospital, or doctor, without delay. Oxygen or artificial respiration should be administered as needed. Asthmatic-type symptoms may develop and may be immediate or delayed up to several hours. Treatment is essentially symptomatic. A physician should be consulted. Ingestion: If swallowed do NOT induce vomiting. If vomiting occurs, lean patient forward or place on left side (headdown position, if possible) to maintain open airway and prevent aspiration. Observe the patient carefully. Never give liquid to a person showing signs of being sleepy or with reduced awareness: i.e. becoming unconscious. Give water to rinse out mouth, then provide liquid slowly and as much as casualty can comfortably drink Seek medical advice

HAZARD STATEMENTS: Causes serious eye irritation. May cause allergy or asthma symptoms or breathing difficulties if inhaled. Fatal if inhales. Causes skin irritation. May cause an allergic skin reaction. Harmful to aquatic life with long lasting effects.

IN CASE OF FIRE: Small quantities of water in contact with hot liquid may react violently with generation of a large volume of rapidly expanding hot sticky semi-solid foam. Presents additional hazard when fire fighting in a confined space. Foam. Dry chemical powder.

MicrobeBlock Sealer

CLEAR





431 Stephenson Hwy. Troy, MI 48083 USA 800.456.6255 | tri-chem.com EMERGENCIES: 800.535.5053

> #MBSC1.5 0.5 Gallon (64 fl oz)

SHIPPING STATEMENT: NOT REGULATED

PRECAUTIONARY STATEMENTS: If medical advice is needed, have product container or label at hand. Keep out of reach of children. Do not handle until all safety precautions have been read and understood. Do not breathe dust/fume/gas/mist/vapors/ spray. Wear protective gloves/protective clothing/eye protection/ face protection. Use only outdoors or in a well-ventilated area. IF INHALES: Remove victim to fresh air and keep at rest in a position comfortable for breathing. IF ON SKIN (or hair): Remove/ take off immediately all contaminated clothing. Rinse skin with water/shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor. Store in a well-ventilated place. Keep container tightly closed. Store locked up. Dispose of contents/container in accordance with local regulations.

SIGNAL WORD: DANGER HAZARD PICTOGRAMS:





DIRECTIONS: See TDS for proper surface preparation instructions. Mixing: If using regular cure material, pot life is 35 minutes at 77 degrees. Pot life of fast cure material is 15 minutes. Work times are shortened by higher temperatures. Pouring material on floor immediately after mixing will extend work time. Combining ratio is 2 part A to 1 part B. If using pigmented material, stir Part A well, bringing settled pigments up from bottom of container before adding Part B. Proportion the amounts carefully and mix for 2 full minutes using a low speed drill, scraping the bottom and sides of the mixing vessel. Application: Apply with brush or roller.